




# Montageanleitung



- EN Installation manual
- FR Instructions de montage
- NL Montagehandleiding
- IT Guida per il montaggio
- ES Instrucciones de montaje
- PT Instruções de montagem
- PL Instrukcja montażu
- CZ Montážní návod
- SI Navodila za vgradnjo
- RU Руководство по монтажу
- CR Odnakivanje uputstvo
- HR Uputstvo za ugradnju
- LV Uzstādīšanas instrukcija
- LT Montavimo instrukcija
- RO Instrucțiune de montaj
- HU Szerelési útmutató
- HR Uputstvo za ugradnju
- BG Монтаж на вентилатор

STG ZRO ZMA SF



A	1
B	1
C	1
D	1
E	1
F	7

